

I	
Idle speed adjustment	115
Ignition switch	14
Indicator	
Drive mode indicator	27
Gear position indicator	27
Neutral indicator	22
Oil/coolant high temperature indicator	22
Reverse indicator	22
Inspection, pre-ride	52
L	
Loading	
Loading guidelines and procedures	56
Weight limits	55
Lubrication	
(see Engine oil, Gear case oil and differential oil)	
M	
Maintenance	
Precautions	102
Schedule	100
Modifications	60
Multi-function display	24
N	
Neutral indicator	22
Noise emission control system	172
O	
Obstacles, riding over	96
Odometer	29
Oil (see Engine oil, Gear case oil and differential oil)	
Oil change Indicator	28
Oil filler cap	42, 117
Oil filter, changing	120
Oil/coolant high temperature indicator	22
Owner's manual compartment	47