

Digital Clock

When selected, the digital clock (1) (Fig. 2-22) shows the time while the ignition is I (ON). To change the display from hourmeter to digital clock, press and release the hourmeter/digital clock select button (2).




Fig. 2-22 (1) Digital clock
(2) Hourmeter/digital clock select button