


Indicators & Displays

Drive Mode Indicator

The drive mode indicator (1) shows the selected drive mode when the ignition switch is in the ON (I) position.

The indicator shows: LOW, D1, D2, and ESP (page 72).

LOW indicator will be displayed when the gearshift lever is in LOW (L) in the ESP mode.



(1) drive mode indicator