

Maintenance Schedule

ITEMS	FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
		FIRST ⇔	km	150	1000	2000	
			mi	100	600	1200	
		NOTE	HOURS	20	100	200	
DRIVESHAFT BOOTS						159	
REAR FINAL GEAR CASE OIL AND DIFFERENTIAL OIL				(REVERY 2 YEARS)		117, 119	
* BRAKE FLUID		NOTE 3				140	
* BRAKE SHOES WEAR		NOTE 1				148	
* BRAKE PADS WEAR		NOTE 1, 2				143	
* BRAKELIGHT SWITCH						149	
BRAKE SYSTEM						140	
* REVERSE LOCK SYSTEM						131	
SKID PLATES, ENGINE GUARD						158	
* CLUTCH SYSTEM						130	
* SUSPENSION						—	
* SPARK ARRESTER					C	C	138
* NUTS, BOLTS, FASTENERS							—
** WHEELS/TYRES							151
** STEERING SHAFT HOLDER BEARINGS							—
** STEERING SYSTEM							—

* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official *Honda Shop Manual*.

** In the interest of safety, we recommend these items be serviced only by your Honda dealer.