


# Air Cleaner

## Dust Cover

### UNDER SEAT



(1) dust cover

(2) breather joint

Do not push the dust cover (1) too far into the breather joint (2).  
If the dust cover is dirty, clean it.