

Maintenance Schedule

FREQUENCY ITEMS		WHICHEVER COMES		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
		FIRST	km	150	1000	2000	
		⇒	mi	100	600	1200	
		NOTE	HOURS	20	100	200	
	REAR FINAL GEAR CASE OIL				(R:EVERY 2 YEARS)		115
*	BRAKE FLUID	NOTE 3					136
*	BRAKE SHOES WEAR	NOTE 1					144
*	BRAKE PADS WEAR	NOTE 1, 2					139
*	BRAKELIGHT SWITCH						145
	BRAKE SYSTEM						136
*	REVERSE LOCK SYSTEM						127
	SKID PLATES, ENGINE GUARD						154
*	CLUTCH SYSTEM						126
*	SUSPENSION						—
*	SPARK ARRESTER				C	C	134
*	NUTS, BOLTS, FASTENERS						—
**	WHEELS/TYRES						147
**	STEERING SHAFT HOLDER BEARINGS						—
**	STEERING SYSTEM						—

- * Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Shop Manual.
- ** In the interest of safety, we recommend these items be serviced only by your Honda dealer.