


# Controls & Features

---

## Drive Mode Select Switch

The drive mode select switch (1) has two positions, AUTO and ESP. See *Shifting Gears* page 70.



(1) drive mode select switch