



Indicators & Controls

This section shows the location of all indicators and controls you would normally use before or while riding your ATV.

The items listed on this page are described in this section. Instructions for other components are presented in other sections of this manual where they will be most useful.

Operation Component Locations	22
Indicator	25
Neutral Indicator Lamp	25
Controls & Features	26
Fuel Valve	26
Choke Lever	27
Ignition Switch.....	28
Start Button	29
Engine Stop Switch.....	30
Throttle Lever	31
Front Brake Lever.....	32
Rear Brake Lever	32
Rear Brake Pedal.....	33
Parking Brake	34
Flag Pole Bracket	35

