

Check the tires for cuts, imbedded nails or other sharp objects. Check the runs for dents or deformation. If there is any damage, see your authorized Honda dealer for repair, replacement, and balancing.

WARNING:

- **Improper tire inflation will cause abnormal tread wear and create a safety hazard. Underinflation may result in the tire slipping on, or coming off of the rim.**
- **Operation with excessively worn tires is hazardous and will adversely affect traction and handling.**

Replace tires before tread depth at the center of the tire reaches the following limit:

Minimum tread depth	
Front:	1,5 mm (1/16 in)
Rear:	2,0 mm (3/32 in)

Vérifier s'il n'y a pas de coupures ou de pénétrations de clous ou autres objets pointus dans les pneus. Examiner également s'il n'y a pas de bosses ou de déformations sur les jantes. Si vous décelez la présence de dégâts, prenez contact avec votre concessionnaire Honda pour réparation, remplacement et équilibrage.

ATTENTION:

- **Un gonflage inapproprié des pneus provoquera une usure anormale de leur surface de roulement et, par conséquent, un danger. Un gonflage insuffisant peut provoquer un glissement ou un déjantement du pneu sur la jante.**
- **L'emploi de pneus trop usés est dangereux, car il gêne la traction et la tenue de route.**

Remplacer les pneus si la profondeur de leurs dessins au centre atteint la limite suivante:

Profondeur minimale du dessin du pneu	
Avant:	1,5 mm
Arrière:	2,0 mm