## **OPERATION**

## PRE-RIDE INSPECTION

## **A**WARNING

\* If the Pre-ride Inspection is not performed, severe personal injury or vehicle damage may result.

Inspect your motorcycle every day before you ride it. The items listed here will only take a few minutes to inspect, and in the long run they can save time, expense, and possibly your life.

- 1. Engine oil level—add engine oil if required (page 30). Check for leaks.
- 2. Fuel level—fill fuel tank when necessary (page 27). Check for leaks.
- 3. Coolant level—add coolant if required. Check for leaks (pages 24—25).
- 4. Front and rear brakes—check operation; make sure there is no brake fluid leakage. (pages 18—21).

- 5. Tyres—check condition and pressure (pages 31—33).
- Drive chain—check condition and slack (pages 65—69). Adjust and lubricate if necessary.
- 7. Throttle—check for smooth opening and closing in all steering positions.
- Lights and horn—check that headlight, tail/stoplight, turn signals, indicators and horn function properly.
- 9. Engine stop switch—check for proper function (page 35).
- Ignition cut-off system—check for proper function (page 71).

Correct any discrepancy before you ride. Contact your authorized Honda dealer for assistance if you cannot correct the problem.