

MAINTENANCE SCHEDULE

The following items require some mechanical knowledge. Certain items (particularly those marked * and * *) may require more technical information and tools. Consult your authorized Honda Dealer.

Perform the Pre-ride Inspection (page 46) at each scheduled maintenance period.

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY

C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			x 1,000 km	1	6	12	18	24	30	36	
			x 1,000 mi	0.6	4	8	12	16	20	24	
			6	12	18	24	30	36			
* FUEL LINE					I		I		I	—	
* THROTTLE OPERATION					I		I		I	68	
* CARBURETOR CHOKE					I		I		I	—	
AIR CLEANER	(NOTE 2)					R			R	—	
* VALVE CLEARANCE			I				I			—	
SPARK PLUG				I	R	I	R	I	R	65—67	
ENGINE OIL			R		R		R		R	61—64	
ENGINE OIL FILTER			R		R		R		R	62—64	
* CARBURETOR SYNCHRONIZATION			I		I		I		I	—	
* CARBURETOR IDLE SPEED			I	I	I	I	I	I	I	69	
RADIATOR COOLANT	(NOTE 3)				I		I		R	25—26	
* COOLING SYSTEM					I		I		I	—	
* SECONDARY AIR SYSTEM	(NOTE 4)				I		I		I	—	