

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE	
			× 1,000 km	1	6	12	18	24	30	36		
			× 1,000 mi	0.6	4	8	12	16	20	24		
											EVERY 1,000 km (600 mi) I, L	108–112
							I		I		I	113
		NOTE (3)				I	I	R	I	I	R	31–33
						I	I	I	I	I	I	122
						I		I		I		31–33, 124
*							I		I		I	130
*							I		I		I	–
							I		I		I	34
		NOTE (3)				I	I	R	I	I	R	34
							I		I		I	115
*							I		I		I	114
*						I		I		I		–
**							I		I		I	–
**						I		I		I		–