



Instruments, Controls, & Other Features

The HISS indicator starts flashing every 2 seconds for 24 hours after the ignition switch is turned OFF. To prevent or to restore the HISS indicator flashing:

1. With the ignition switch ON, press and hold the **A** button (➡P.20) for 2 seconds or more when the display function mode is odometer.
 - ▶ The HISS indicator flashes once.
2. Turn the ignition switch OFF.

EC Directive

This immobilizer system complies with R & TTE (Radio and Telecommunications Terminal Equipment and the mutual recognition of their conformity) Directive.



The declaration of conformity to R & TTE Directive is provided to the owner at the time of purchase. The declaration of conformity should be kept at a safe place. When the declaration of conformity is lost or is not provided, contact your dealer.

Information

South Africa only

