


## Fuel mileage meter & Average speed



## Fuel mileage meter & Average speed

**SET** button switches between the current fuel mileage, the average fuel mileage and the average speed.



## Current fuel mileage

Displays the current or instant fuel mileage.  
Display range: 0.1 to 99.9 km/L (L/100km, mile/L or mile/gal)

- When your speed is less than 7 km/h (5 mph): "--.-" is displayed
- Less than 0.1 km/L (L/100km, mile/L or mile/gal) or more than 99.9 km/L (L/100km, mile/L or mile/gal) : "--.-" is displayed

When "--.-" is displayed except for the above-mentioned case, go to your dealer for service.