


Seat/Document Bag

The document bag is located under the seat to store the owner's manual (3) and other documents. Release the helmet holder with the ignition key (1) and pull the seat lock levers (2) backward. Then remove the seat (4) by lifting and sliding it backward.



Steering Lock

The steering can be locked when the ignition switch (1) is in "LOCK" position.

Turn the handlebar all the way to the steering stop, either to the left or right, insert the key at the "OFF" position turn it counterclockwise to "LOCK" position while pushing in and then remove the key. To unlock, only turn the key clockwise.

