

## Fairing Pockets

The fairing pockets (1) can be removed with a key (2).

### NOTE:

- \* Do not exceed 1.0 kg (2.2 lbs) when storing in the fairing pocket.
- \* Water may get into the fairing pocket. Be careful when storing valuables in the fairing pocket.

