

Installation Notes:

To install the front wheel assembly, position the wheel between the fork legs. Lower the forks so the hollows in the fork legs rest on top of the axle.

CAUTION: When installing the wheel, fit the left brake disc carefully between the brake pads to avoid damaging the pads.

Position the lug on the speedometer gearbox against the lug (8) on the left fork leg. Install the axle holders (7) with the F mark (9) forward. Tighten the forward axle holder nuts lightly.

