To close the fuel tank cap, align the latch in the cap with the slot in the filler neck. Push cap into the filler neck until it snaps closed and locks. Remove the key and close the tank cap cover.

## **A**WARNING

- \* Gasoline is extremely flammable and is explosive under certain conditions.
- \* Refuel in a well-ventilated area with the engine stopped. Do not smoke or allow flames or sparks in the area where the engine is refueled or where gasoline is stored.
- \* Do not overfill the tank (there should be no fuel in the filler neck (3)). After refueling, make sure the fuel cap is closed securely.
- \* Be careful not to spill fuel when refueling. Spilled fuel or fuel vapor may ignite. If any fuel is spilled, make sure the area is dry before starting the engine.
- \* Avoid repeated or prolonged contact with skin or breathing of vapor. KEEP OUT OF REACH OF CHILDREN.