A WARNING

* Do not downshift when traveling at a speed that would force the engine to overrev in the next lower gear; the rear wheel may lose traction, resulting in a possible loss of vehicle control.

CAUTION:

- * Do not shift gears without disengaging the clutch and closing the throttle. The engine and drive train could be damaged by overspeed and shock.
- * Do not tow the motorcycle or coast for long distances while the engine is off. The transmission will not be properly lubricated and damage may result.
- * Do not exceed 13,500 min⁻¹ (rpm) when running the engine without a load. Serious engine damage may result.

NOTE:

* The battery will not charge while the engine speed is below 1,500 min⁻¹ (rpm). Avoid idling for prolonged periods, or continuous operation below 1,500 min⁻¹ (rpm). * Be careful when revving the engine or accelerating in 1st or 2nd gear as the engine will easily enter the tachometer red zone.