

| (Ref.No.) Description                            | Function  |
|--|---|
| (6) High coolant temperature indicator (red)     | <p>Lights when the coolant is over the specified temperature. If the indicator goes on while riding, stop the engine and check the reserve tank coolant level. Read pages 28 – 29 and do not ride the motorcycle until the problem has been corrected.</p> <p><b>NOTICE</b></p> <p>Exceeding maximum running temperature may cause serious engine damage.</p> |
| (7) Odometer/Tripmeter/<br>Digital clock display | Shows odometer, tripmeter and digital clock. This display shows the initial display (page 17 ).   |
| Odometer   | Shows accumulated mileage (page 18 ).   |
| Tripmeter 1 and 2                                | Shows mileage per trip (page 18 ).  |
| Digital clock                                    | Shows hour and minute (page 19 ).   |