

ITEM	FREQUENCY	WHICHEVER →		ODOMETER READING [NOTE (1)]								REFER TO PAGE
		COMES FIRST ↓	x 1,000 km	1	6	12	18	24	30	36		
			x 1,000 mi	0.6	4	8	12	16	20	24		
		NOTE	MONTH		6	12	18	24	30	36		
DRIVE CHAIN				EVERY 1,000 km (600 mi) I, L								60-65
BRAKE FLUID	(NOTE 4)			I	I	R	I	I	R		14-15	
BRAKE SHOE/PAD WEAR				I	I	I	I	I	I		67,68	
BRAKE SYSTEM				I		I		I		I	14-17	
* BRAKE LIGHT SWITCH						I		I		I	76	
* HEADLIGHT AIM						I		I		I	-	
CLUTCH SYSTEM				I	I	I	I	I	I	I	18-19	
SIDE STAND						I		I		I	66	
* SUSPENSION						I		I		I	-	
* NUTS, BOLTS, FASTENERS				I		I		I		I	-	
** WHEELS/TYRES				I	I	I	I	I	I	I	-	
** STEERING HEAD BEARINGS				I		I		I		I	-	