



Front/Rear Turn Signal Bulb

1. Remove the turn signal lens (1) by removing the two screws (2).



(1) Turn signal lens
(2) Screws

2. Slightly press the bulb (3) and turn it counterclockwise.
3. Install a new bulb in the reverse order of removal.



(3) Bulb