## **Clutch System**

Your motorcycle's manually-activated, wet, multiplate clutch is part of the primary drive system. Proper freeplay adjustment allows a smooth, gradual engagement when shifting gears.


Improper freeplay adjustment can cause premature clutch wear.

## **Clutch Freeplay**



Refer to Safety Precautions on page 56.

## **LEFT HANDLEBAR**



(1) clutch lever