

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [ NOTE (1) ]								Refer to page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
	FINAL DRIVE OIL				I			I		R	30, 77
	BRAKE FLUID	NOTE (4)			I	I	R	I	I	R	19
	BRAKE SHOES/PADS WEAR				I	I	I	I	I	I	92, 93
	BRAKE SYSTEM			I				I		I	18, 92, 93
*	BRAKELIGHT SWITCH					I		I		I	100
*	HEADLIGHT AIM					I		I		I	49
	CLUTCH SYSTEM			I	I	I	I	I	I	I	22
	SIDE STAND					I		I		I	82
*	SUSPENSION					I		I		I	81
*	NUTS, BOLTS, FASTENERS			I		I		I		I	—
**	WHEELS/TYRES			I	I	I	I	I	I	I	—
**	STEERING HEAD BEARINGS			I		I		I		I	—