

TOOL KIT


The tool kit (1) is in the compartment box (2) behind the left side cover.

Remove the left side cover (page 47).

Open the compartment box cover (3), insert the ignition key (4) into the lock and turn it counterclockwise to unlock the compartment.

Some roadside repairs, minor adjustments and parts replacement can be performed with the tools contained in the kit.

- 10 × 14 mm Open end wrench
- 12 × 17 mm Open end wrench
- 8 mm Open end wrench
- Pliers
- 4 mm Hex wrench
- 5 mm Hex wrench
- 6 mm Hex wrench
- No. 2 Phillips screwdriver
- No. 2 screwdriver
- Screwdriver handle
- Spark plug wrench
- Pin spanner
- Tool bag



- (1) Tool kit
- (2) Compartment box
- (3) Compartment box cover
- (4) Ignition key