


Digital Clock

Shows hour and minute. To adjust the time, proceed as follows:

1. Turn the ignition switch ON.
2. Show the digital clock (1).
3. Push and hold the odometer/tripmeter/digital clock select and reset button (2) for more than 2 seconds. The clock will be set in the adjust mode with the hour display flashing.



- (1) Digital clock
(2) Odometer/Tripmeter/Digital clock select and reset button

4. To set the hour, push the odometer/tripmeter/digital clock select and reset button until the desired hour is displayed.
 - The time is advanced by one hour, each time the button is pushed.

