

HELMET HOLDER

The helmet holder is located below the seat.

Remove the seat (page 52).


Hang the helmet on the holder hook (1).

Install the seat and make sure it is locked.

⚠ WARNING

Riding with a helmet attached to the holder can interfere with the rear wheel or suspension and could cause a crash in which you can be seriously hurt or killed.

Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.



(1) Holder hook