


Switches

Ignition Switch

The ignition switch operates the electrical circuits.

Do not touch the switch whilst riding.

Turning the ignition switch to 'OFF' or 'LOCK' disables the electrical system.



Advice

- The headlamp turns "ON" when the ignition switch is "ON". Thus the battery will become flat if the ignition switch is left "ON" without the engine running.



Tip

- Lock the handlebars and pull the key out whenever you leave the vehicle.

Key position	Function	Remove Key
ON	Start, day/night ops <ul style="list-style-type: none">Headlamp 'ON'Able to use turn signals horns, and stops lamps	Unable
OFF	Stop <ul style="list-style-type: none">All electrical systems disabled	Yes
LOCK	Handlebar lock engaged <ul style="list-style-type: none">All electrical systems disabled	YES