


Engine Stop Switch

The engine stop switch allows you to stop the engine immediately in an emergency situation. The engine stop switch should be left in RUN position during normal riding and used only in case of emergency.

Switching between RUN and OFF whilst riding leads to unstable engine running and riding stability. It may also damage the engine.

Engine Stop Switch



Advice

If using this switch in an emergency stopped engine, turn the ignition switch OFF to avoid battery becoming flat.