

Maintenance Schedule

The following Maintenance Schedule specifies all maintenance required to keep your motorcycle in peak operating condition. Maintenance work should be performed in accordance with standards and specifications of Honda by properly trained and equipped technicians. Your authorised Honda dealer meets all of these requirements. Perform the Pre-ride Inspection (page 41) at each scheduled maintenance period.

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY
C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE

ITEM	FREQUENCY	NOTE	ODOMETER READING [NOTE (1)]								*Refer to Service Manual
			x 1,000km	1	6	12	18	24	30	36	
			x 1,000mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
* FUEL LINE					I		I		I	-	
* THROTTLE OPERATION					I		I		I	-	
* CARBURETOR CHOKE					I		I		I	-	
* AIR CLEANER	(NOTE 2)				I	I	R	I	I	R	-
CRANKCASE BREATHER	(NOTE 3)				C	C	C	C	C	C	-
SPARK PLUG					I	R	I	R	I	R	-
* VALVE CLEARANCE					I		I		I	-	
ENGINE OIL					R	R	R	R	R	R	-
ENGINE OIL FILTER					R		R		R	R	-
* CARBURETOR SYNCHRONISATION					I		I		I	I	-
* ENGINE IDLE SPEED					I	I	I	I	I	I	-
RADIATOR COOLANT	(NOTE 4)					I		I		R	-
* COOLING SYSTEM						I		I		I	-