


Odometer/Tripmeter Display

The display (1) has two functions: odometer and tripmeter.

The tripmeter will show mileage as in two sub modes, "TRIP 1" and "TRIP 2".

Push the button (2) to select "ODO", "TRIP 1" and "TRIP 2" mode.


To reset the tripmeter, push and hold the button when the display is in the "TRIP 1" and "TRIP 2" mode.




(1) Odometer/Tripmeter display

(2) Odometer/Tripmeter select and reset button


ODO



TRIP 1



TRIP 2



Tripmeter
reset

