

MAJOR COMPONENTS (Information you need to operate this motorcycle)

▲ WARNING

- * **If the Pre-ride Inspection (page 30) is not performed, severe personal injury or vehicle damage may result.**

SUSPENSION

Front Suspension

The front suspension system uses air assisted front forks with compression damping adjuster. The forks may be adjusted for the rider's weight and riding conditions by adjusting the compression damping air pressure and oil volume. Use the chart right to determine the correct adjustment for you.

Standard air pressure:

0 kPa (0 kg/cm², 0 psi)

Maximum air pressure

100 kPa (1.0 kg/cm², 15 psi)