

| Condition | Air pressure | Oil volume |
|--|--------------|------------|
| The entire range of travel is too hard. | Reduce | — |
| The entire range of travel is too soft (bottoming). | Increase | — |
| Initial travel is good, but the final stages of travel are too soft (bottoming). | — | Increase |
| The initial stages of travel are good but the final stages are hard. | — | Reduce |
| The initial stages of travel are too soft, but the final stages are good. | Increase | Reduce |
| The initial stages of travel are too hard, but the final stages are good. | Reduce | Increase |