

MAINTENANCE SCHEDULE

Perform the Pre-ride Inspection (Page 30) at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary.

C: Clean R: Replace A: Adjust L: Lubricate

ITEM	FREQUENCY	NOTE	RUNNING-IN MAINT.	REGULAR MAINT. INTERVAL	Refer to
			First week of operation (about 200 mi, 350 km)	Every 30 operating days (about 100 mi, 1600 km)	
* FUEL LINE				I	—
** FUEL STRAINER SCREEN				C	—
* THROTTLE OPERATION				I	56
AIR CLEANER		NOTE 1		C	46
SPARK PLUG				I	51
* VALVE CLEARANCE			I	I	53
ENGINE OIL			R	R	48
ENGINE OIL STRAINER SCREEN				C	48
** ENGINE OIL CENTRIFUGAL FILTER				C	—
* CAM CHAIN TENSION			A	A	55
* DECOMPRESOR SYSTEM			I	I	58
* CARBURETOR IDLE SPEED			I	I	59