

ITEM	FREQUENCY	NOTE	RUNNING-IN MAINT.	REGULAR MAINT. INTERVAL	Refer to
			First week of operation (about 200 mi, 350 km)	Every 30 operating days (about 100 mi, 1600 km)	
	DRIVE CHAIN	NOTE 1	I, L	Every 10 operating days (about 300 mi, 500 km) I, L	60
	DRIVE CHAIN SLIDER		I	I	61
	BRAKE SHOE WEAR			I	73
	BRAKE SYSTEM		I	I	17-20
*	HEADLIGHT AIM			I	—
	CLUTCH SYSTEM		I	I	21-22
	SIDE STAND			I	67
*	SUSPENSION			I	65, 66
*	NUTS, BOLTS, FASTENERS		I	I	—
**	WHEELS/TYRES		I	I	72
**	STEERING HEAD BEARINGS		I	I	—

\* SHOULD BE SERVICED BY AN AUTHORIZED HONDA DEALER, UNLESS THE OWNER HAS PROPER TOOLS AND SERVICE DATA AND IS MECHANICALLY QUALIFIED. REFER TO THE OFFICIAL HONDA SERVICE MANUAL.

\*\* IN THE INTEREST OF SAFETY, WE RECOMMEND THESE ITEMS BE SERVICED ONLY BY AN AUTHORIZED HONDA DEALER.

NOTE: 1. Service more frequently when ridden in wet or dusty conditions.