

BRAKE PAD WEAR

(Refer to the maintenance precautions on page 59).

Brake pad wear depends upon the severity of usage, the type of riding, and riding area conditions. (Generally, the pads will wear faster on wet and dirty riding terrain.)


Inspect the pads at each regular maintenance interval (page 56).

Front/Rear Brake


Check the cutout (1) in each pad.

If either pad is worn to the cutout, replace both pads as a set. See your Honda dealer for this service.

< FRONT BRAKE >



< REAR BRAKE >



(1) Cutout