

Instruments


Engine Stop switch:

The Engine Stop switch allows you to stop the engine immediately in an emergency situation.

The Engine Stop switch should be left in the "RUN" position during normal riding and only used in case of Emergency.

Switching between "RUN" and "OFF" whilst riding will lead to unstable engine operation, backfiring and probable engine damage.

Engine Stop Switch



 - ADVICE -

If using this switch in an emergency situation, switch the Ignition Switch to the "OFF" position, to avoid the battery going flat.