

Riding the Motorcycle

Selecting a gear

The transmission is a six-speed Manual Transmission:

- When changing gear, release the throttle and pull in the clutch lever.
- Move the gear shift pedal with your toe until you feel the detent on each gear position. Do not force the pedal or shift without using the Clutch or Transmission damage may occur.

