

## Brake pad Inspection:

### [Front]

Look at the brake caliper from the bottom and check the brake pad wear indicators. If the indicator grooves have reached the side of the brake disc, the pads should be replaced.


### [Rear]

Look at the brake caliper from behind and check the brake pad wear indicators. If the indicator grooves have reached the side of the brake disc, the pads should be replaced.

When replacing brake pads, always replace both sides at the same time.

Please consult your Honda dealer for brake pads change.

[Front]



[Rear]

