

Flooded Engine

If the engine fails to start after repeated attempts, it may be flooded with excess fuel. To clear a flooded engine, push the choke lever down to Fully OFF (C). Pull and hold the manual decompressor lever. Open the throttle fully and crank the engine several times with the kickstarter while pushing the engine stop button. Release the decompressor lever, the engine stop button and follow the "High Air Temperature" Starting Procedure (page 48).

RUNNING-IN

Help assure your motorcycle's future reliability and performance by paying extra attention to how you ride during the first operating day or 25 km (15 miles).

During this period, avoid full-throttle starts and rapid acceleration.