



Initial Display

1. When the ignition switch is turned ON, the digital tripmeter will temporarily display all the modes and digital segments so you can make sure the liquid crystal display is functioning properly.



2. After replacing the battery, the digital tripmeter will display all the modes and digital segments first, then the display will indicate "1 : 00" in CLOCK mode and "minutes" will blink. This indicates that all the memories of the tripmeter, elapsed time meter and clock functions have been erased.



You cannot set the digital tripmeter to any modes while "minutes" are blinking in CLOCK mode.

To set the meter to a specific mode, press the RESET-TIME button. This will temporarily set the digital tripmeter in CLOCK mode, allowing it to be set to any desired mode.

