

Safe maintenance.....	38	Engine oil.....	60
Daily / regular checks, easy maintenance.....	41	Inspecting the engine oil level.....	60
Daily checks.....	43	Engine oil type.....	61
Regular inspections.....	46	Clutch.....	65
Easy maintenance.....	48	Inspecting clutch lever play.....	65
Brakes.....	49	Battery.....	67
Front brake.....	49	Removing/attaching battery.....	68
Brake lever play (check).....	49	Fuse.....	70
Rear brake.....	50	Inspecting the fuse & replacement.....	70
Brake pedal play (check).....	49	Air cleaner.....	72
Front / rear brakes.....	53	Air cleaner installation / removal.....	72
Brake shoe wear checks.....	53	Checking the air cleaner element.....	73
Tires.....	54	Cleaning the air cleaner element.....	74
Inspecting tire pressures.....	67	Cable / wires.....	75
Checking for signs of damage.....	55	Checking rubber boots.....	75
Abnormal wear checks.....	56	Checking cables and wiring condition.....	75
Tread depth checks.....	56		
Replacement tires.....	57		
Drive chain.....	58		
Inspecting chain adjustment.....	58		
Applying lubricant / cleaning.....	59		