

Using the switches

Ignition/Main switch

The main switch controls the on/off for the electrical system.

NEVER operate the switch when traveling.

When the main switch key is "OFF", the electrical system will not work. Operating the main switch while traveling may result in unexpected accidents, only operate this switch when the vehicle is stationary.

Key position	Usage	Key
ON	Start Day/Night riding Horn, indicators, brake light will operate	Key cannot be removed
OFF	Stop Electrical system is completely shut OFF	Key can be removed

NOTICE

When leaving the motorcycle, always apply the handle lock and remove the key.

