


Checking front/rear brake

wear

Check that the indicator on the brake arm and the grooved point on the brake panel are not overlapping each other. If the two points are overlapping each other, it shows that the brake shoes have worn to their limit and will need replacement.

Contact your HONDA dealer for replacement of the brake shoes.

Front wheel



Rear wheel

