



- (1) DUST COVER
- (2) LOCK NUT
- (3) ADJUSTER
- (A) DECREASE
- (B) INCREASE

Throttle Grip

Throttle Grip Free Play

Standard throttle grip free play is approximately 3 mm (0.12 in) of grip rotation.

Adjustment is made with the integral throttle cable adjuster.

Slide the dust cover off from the integral cable adjuster. Turning the adjuster in direction "A" will decrease free play and turning it in direction "B" will increase free play. Tighten the lock nut after adjustment.

Operate the throttle grip to ensure that it functions smoothly and returns completely in all steering position.



- (1) HEADLIGHT DIMMER SWITCH

Headlight dimmer switch

Turn the dimmer switch to  to select high beam or to  to select low beam.



- (1) TURN SIGNAL SWITCH

Turn signal switch

Move to  to signal a left turn,  to signal a right turn. Press to turn signal off.