


Operating instructions



(1) HORN BUTTON

Horn button


Press the button to sound the horn.



(1) MAGNETIC STOP SWITCH

Magnetic stop switch

Pull the stop magnetic switch (red) until the engine stops completely.



4ED

- (1) MAPPING SWITCH
- (2) MODE 1
- (3) MODE 2

Mapping switch

The ECU for the Cota 300RR (4ED) PGM-FI electronic injection system has two operational maps which can be selected depending on the conditions:

Switch in Mode 1:
Standard

Switch in Mode 2:
Powered