

## Keys

### Ignition Key

Be sure to record the key number provided with the original keys and record it in this manual. Store the spare key in a safe location.

To make a duplicate, take the spare key or the key number to your dealer.

If you lose all keys and the key number, the ignition switch assembly will probably have to be removed by your dealer to determine the key number.

A metal key holder may cause damage to the area surrounding the ignition switch.

## Instruments, Controls, & Other Features

### Ignition Switch

Leaving the ignition switch in the **I** (On) position with the engine stopped will drain the battery.

Do not turn the key while riding.

### Odometer

The display locks at 999,999.9 when the read-out exceeds 999,999.9.

### Owner's Manual

The owner's manual, registration, and insurance information can be stored in the document compartment on the reverse side of the seat.