

13. REAR FENDER/ EXHAUST PIPE

REAR FENDERS

13-1

EXHAUST PIPE


13-3

REAR FENDERS

REMOVAL

Remove the seat.


Remove the fender four bolts and two screws.



Remove the fender stay nuts.

Remove the rear grab rail bolts and the grab rail.

Remove the fenders.



13