




## HANDLEBAR


### REMOVAL

Remove the two screws attaching the front brake master cylinder holder to the master cylinder.  
Remove the master cylinder.

Remove the two screws attaching the throttle lever housing.  
Remove the throttle lever housing.



Remove the two screws attaching the clutch lever housing.  
Remove the clutch/parking lever housing.  
Remove the dimmer switch by removing the attaching screws.



Remove the handlebar upper holders and handlebar.

