

GENERAL INFORMATION

TOOLS

SPECIAL

DESCRIPTION	TOOL NUMBER	ALTERNATIVE TOOL	TOOL NUMBER	REF. PAGE
Pinion joint holder	07924-HA00000			12-21,12-22,12-29
Pin gear driver	07945-HA00000			12-12
Bearing driver attachment	07946-HA00000	Not available in U.S.A.		10-23
Universal bearing puller	07631-0010000	Commercially available in U.S.A.		10-5,12-20
Socket bit, 17 mm	07703-0020500	Equivalent commercially available in U.S.A.		12-15,12-17,12-18
Lock nut wrench	07908-4690001	Lock nut wrench	KS-HBA-08-469	12-15,12-18
Steering stem socket	07916-3710100			11-27,11-29
Lock nut wrench, 34 x 44 mm	07916-ME50001	Lock nut wrench	07916-ME50000	10-18,10-25,12-22,12-25
Clutch holder	07923-HA80000			
Clutch puller	07933-HA80000			
Hex wrench, 6 mm	07917-3230000	Equivalent commercially available in U.S.A.		11-21
Clutch center holder	07923-KE10001			8-15,8-18
Shaft holder	07924-ME50000			10-17,10-18,10-25
Crank assembly kit	07931-KF00000			10-8
- Assembly collar	07931-KF00100			10-8
- Threaded adapter	07931-KF00200			10-8
- Shaft puller	07931-ME40000	Shaft puller	07931-ME4000A	10-8,12-22
Bearing remover, 17 mm	07936-3710300			8-8,10-7,10-13
Remover handle	07936-3710100			8-8,10-7,10-13,12-16
Remover weight	07741-0010201	Remover weight	07936-3710200	8-8,10-7,12-16
Bearing remover set, 20 mm	07936-3710001	Not available U.S.A.		8-8
- Bearing remover, 20 mm	07936-3710600			8-8
- Remover handle	07936-3710100			8-8
- Remover weight	07741-0010201	Remover weight	07936-3710200	8-8
Bearing remover set	07936-8890101			12-16
- Bearing remover assy	07936-8890300			12-16
- Bearing remover	07936-8890200			12-16
- Remover weight	07741-0010201	Remover weight	07936-3710200	12-16
Bearing remover set, 15 mm	07936-KC10000	Not available in U.S.A.		10-20
- Bearing remover, 15 mm	07936-KC10500			10-20
- Remover weight	07741-0010201	Remover weight	07936-3710200	10-20
Attachment, 28 x 30 mm	07946-1870100			8-8,10-13
Steering stem driver	07946-4300001	Steering stem driver and attachment (U.S.A. only)	07946-MB00000 HG-HT-54	11-28
Ball race remover	07953-3330000			11-28
Valve guide reamer, 5.5 mm	07984-2000000	Valve guide remover (U.S.A. only)	07984-200000A	6-10
Universal bead breaker	GN-AN-958-BB1	U.S.A. only		11-11
Lock nut wrench, 30 x 64 mm	07916-MB00001	Lock nut wrench	07916-MB00000	10-21,10-24,12-6
Water seal driver	07947-HA00000			12-13
Shock absorber base	07959-MB10000			12-19
Collar	07965-GA70101			8-10,8-14
Clutch holder	07923-HA80000	Not available in U.S.A.	07923-HB3000A (U.S.A. only)	
Clutch puller	07933-HA80000	Not available in U.S.A.	07933-HB3000A (U.S.A. only)	8-10
Lock nut wrench attachment	07916-HA0020A	U.S.A. only		10-21
Bearing driver attachment	07946-HA00000			10-23
Bearing remover set, 10 mm	07936-GE00000			9-3
Remover weight	07741-0010201	Remover weight	07936-3710200	9-3
Attachment	07946-3290000			11-9
Lock nut wrench attachment	07916-HA0010A	U.S.A. only		12-22,12-25
Bearing remover set, 10 mm	07936-GE00000			9-3